





YAMAHA

GENUINE

PARTS CATALOGUE


MOTORCYCLE



CYLINDER HEAD


Ref. No.	Part Number	Description	Qty	Remarks
1	26H-11110-01-00	CYLINDER HEAD ASSEMBLY, REAR (26H-11110-00-00)	1	
2	26H-11133-10-00	. GUIDE, INTAKE VALVE	8	
3	93440-12117-00	. CIRCLIP	8	
4	99510-08016-00	. PIN, DOWEL	16	
5	90105-06153-00	. BOLT, WASHER BASED	16	
6	90340-20090-00	. PLUG, STRAIGHT SCREW	3	
7	90201-195F4-00	. WASHER, PLATE	3	
8	95911-08625-00	. BOLT, STUD	4	
9	26H-11112-00-00	CYLINDER HEAD ASS'Y 2	1	
10	26H-11133-10-00	. GUIDE, INTAKE VALVE	8	
11	93440-12117-00	. CIRCLIP	8	
12	99510-08016-00	. PIN, DOWEL	16	
13	90105-06153-00	. BOLT, WASHER BASED	16	
14	90340-20090-00	. PLUG, STRAIGHT SCREW	3	
15	90201-195F4-00	. WASHER, PLATE	3	
16	95911-08625-00	. BOLT, STUD	4	
17	26H-12469-01-00	JOINT 1	2	
18	93210-16629-00	O-RING	2	
19	93210-18322-00	O-RING	2	
20	93210-21631-00	O-RING	2	
21	90254-03008-00	PIN, SPRING	2	
22	NGK-DPR8E-A9-00	NGK DPR8EA-9 10PK	1	UR
23	26H-11181-00-00	GASKET, CYLINDER HEAD 1	2	
24	99510-12016-00	PIN, DOWEL	4	
25	90179-10414-00	NUT	16	
26	90201-102G9-00	WASHER, PLATE	16	
27	26H-11191-01-00	COVER, cyl. head 1	2	
28	90109-064F0-00	BOLT	16	

CONTINUED ON NEXT FRAME ➤



CYLINDER HEAD


Ref. No.	Part Number	Description	Qty	Remarks
29	90209-11262-00	WASHER	16	
30	2GH-1111G-00-00	RUBBER, MOUNT 1	16	
31	90338-10150-00	PLUG	16	
32	26H-11193-00-00	GASKET, HEAD COVER 1	2	
33	26H-13580-00-00	AIR CHAMBER ASSEMBLY ...	1	
34	26H-1111J-00-00	PIPE 1	2	
35	26H-1112J-00-00	PIPE 2	2	
36	90467-11044-00	CLIP	8	



CRANKSHAFT - PISTON


Ref. No.	Part Number	Description	Qty	Remarks
1	1FK-11400-00-00	CRANKSHAFT ASSEMBLY ...	1	
2	1FK-11416-11-00	PLANE BEARING, CRANKSHAFT 1	8	UR
	1FK-11416-21-00	PLANE BEARING, CRANKSHAFT 1	8	UR
	1FK-11416-31-00	PLANE BEARING, CRANKSHAFT 1	8	UR
	1FK-11416-41-00	PLANE BEARING, CRANKSHAFT 1	8	UR
	1FK-11416-51-00	PLANE BEARING, CRANKSHAFT 1	8	UR
	26H-11416-00-00	PLANE BEARING, CRANK 1 ..	8	UR
	26H-11654-00-00	BOLT, CONNECTING ROD ...	8	ur
3	26H-11631-00-A0	PISTON (STD)	4	UR
	26H-11635-00-00	PISTON (1ST O/S 0.25MM)	4	AP
	26H-11636-00-00	PISTON (2ND O/S 0.50MM) ...	4	AP
4	26H-11610-00-00	PISTON RING SET (STD)	4	UR
	26H-11610-10-00	PISTON RING SET (1ST O/S) ..	4	AP
	26H-11610-20-00	PISTON RING SET (2ND O/S) .	4	AP
5	26H-11633-01-00	PIN, PISTON (26H-11633-00-00)	4	
6	93450-19095-00	CIRCLIP	8	
7	1FK-11650-00-00	CONNECTING ROD ASSEMBLY	4	
8	26H-11654-00-00	. BOLT, CONNECTING ROD ..	2	
9	90179-08327-00	. NUT	2	
10	1FK-11656-00-00	PLANE BEARING, CONNECTING ROD	8	UR
	1FK-11656-20-00	PLANE BEARING, CONNECTING ROD	8	UR
	1FK-11656-30-00	PLANE BEARING, CONNECTING ROD	8	UR
	1FK-11656-40-00	PLANE BEARING, CONNECTING ROD	8	UR

CONTINUED ON NEXT FRAME ➤




CRANKSHAFT - PISTON

Ref. No.	Part Number	Description	Qty	Remarks
10	26H-11656-10-00	PLANE BEARING, CONNECTING ROD	8	UR
	26H-11656-50-00	PLANE BEARING, CONNECTING ROD	8	UR
11	90280-05029-00	KEY, WOODRUFF	1	
12	90105-12374-00	BOLT, WASHER BASED	1	
13	90201-121H0-00	WASHER, PLATE	1	
14	1FK-11500-00-00	BALANCER ASSEMBLY	1	
15	26H-11413-01-00	PLANE BEARING, BALANCE WEIGHT	4	UR
	26H-11413-11-00	PLANE BEARING, BALANCE WEIGHT	4	UR
	26H-11413-21-00	PLANE BEARING, BALANCE WEIGHT	4	UR
	26H-11413-31-00	PLANE BEARING, BALANCE WEIGHT	4	UR
	26H-11413-41-00	PLANE BEARING, BALANCE WEIGHT	4	UR
	26H-11413-51-00	PLANE BEARING, BALANCE WEIGHT	4	UR
	26H-11413-61-00	PLANE BEARING, BALANCE WEIGHT	4	UR




CAMSHAFT - CHAIN

Ref. No.	Part Number	Description	Qty	Remarks
1	1NL-12171-00-00	CAMSHAFT 1	2	
2	1NL-12181-00-00	CAMSHAFT 2	2	
3	26H-12176-02-00	SPROCKET, CAM CHAIN	2	
4	26H-12177-01-00	SPROCKET, CAM CHAIN	2	
5	90105-07087-00	BOLT, WASHER BASED	8	
6	94580-81118-00	CHAIN (D.I.D 219FTS118LL) ..	2	
7	94600-02001-00	. JOINT, CHAIN (BF05M)	2	
8	26H-12241-00-00	GUIDE, STOPPER 2	2	
9	26H-12251-00-00	DAMPER, CHAIN 1	2	
10	26H-12252-00-00	DAMPER, CHAIN 2	2	
11	26H-12233-00-00	PLATE, GUIDE STOPPER 1 ...	1	
12	95821-08025-00	BOLT, FLANGE	1	
13	26H-12210-03-00	TENSIONER ASSEMBLY, CAM CHAIN	2	
14	3JP-12213-00-00	GASKET, TENSIONER CASE ..	2	
15	91311-06020-00	BOLT, SOCKET HEAD	4	




VALVE

Ref. No.	Part Number	Description	Qty	Remarks
1	26H-12111-00-00	VALVE, intake	8	
2	26H-12121-00-00	VALVE, exhaust	8	
3	26H-12116-00-00	SEAT, VALVE SPRING	16	
4	26H-12113-00-00	SPRING, VALVE INNER	16	
5	26H-12114-00-00	SPRING, VALVE OUTER	16	
6	26H-12119-00-00	SEAL, valve stem	16	
7	26H-12117-00-00	RETAINER, VALVE SPRING ..	16	
8	4G0-12118-00-00	COTTER, VALVE	32	
9	26H-12153-00-Y0	LIFTER, VALVE	16	
10	26H-12168-00-00	PAD, ADJUSTING (2.00)	16	UR
	26H-12168-20-00	PAD, ADJUSTING (2.05)	16	UR
	26H-12168-40-00	PAD, ADJUSTING (2.10)	16	UR
	26H-12168-60-00	PAD, ADJUSTING (2.15)	16	UR
	26H-12168-80-00	PAD, ADJUSTING (2.20)	16	UR
	26H-12168-A0-00	PAD, ADJUSTING (2.25)	16	UR
	26H-12168-F0-00	PAD, ADJUSTING (2.30)	16	UR
	26H-12168-H0-00	PAD		




VALVE

Ref. No.	Part Number	Description	Qty	Remarks
10	26H-12169-G0-00	PAD, ADJUSTING (3.00)	 16	U.R.
	26H-12169-J0-00	PAD, ADJUSTING (3.05)	 16	U.R.
	26H-12169-L0-00	PAD, ADJUSTING (3.10)	 16	U.R.
	26H-12169-N0-00	PAD, ADJUSTING (3.15)	 16	U.R.
	26H-12169-T0-00	PAD, ADJUSTING (3.20)	 16	U.R.




WATER PUMP

Ref. No.	Part Number	Description	Qty	Remarks
1	26H-12420-01-00	WATER PUMP ASS'Y	1	
2	1FK-12450-00-00	. IMPELLER SHAFT ASSEMBLY	1	
3	93603-14026-00	. PIN, DOWEL	1	
4	26H-12459-00-00	. GEAR, IMPELLER SHAFT (31T)	1	
5	99009-10400-00	. CIRCLIP	2	
6	93306-00004-00	. BEARING	1	
7	93101-10090-00	. OIL SEAL	1	
8	11H-12438-00-00	. SEAL, MECHANICAL	1	
9	93211-16591-00	. O-RING	1	
10	91311-06016-00	. BOLT, SOCKET HEAD	2	
11	3VD-13455-00-00	. PLUG	1	
12	214-11198-01-00	. GASKET	1	
13	26H-15337-01-00	. DAMPER 4	1	
14	90468-98132-00	. CLIP	1	
15	26H-15338-00-00	. DAMPER, ENGINE MOUNT 5	1	
16	26H-W1548-00-00	. COVER 2 ASSEMBLY	1	
17	26H-12449-00-00	GASKET, water pump	1	
18	91311-06025-00	BOLT, SOCKET HEAD	4	
19	99530-10014-00	PIN, DOWEL		




WATER PUMP

Ref. No.	Part Number	Description	Qty	Remarks
28	26H-12413-00-00	COVER, THERMOSTAT	1	
29	93210-45511-00	O-RING	1	
30	98906-06016-00	SCREW, BIND	2	




RADIATOR - HOSE

Ref. No.	Part Number	Description	Qty	Remarks
1	26H-12578-00-00	HOSE 3	1	
2	90460-38285-00	CLAMP, HOSE	2	
3	26H-12461-00-00	RADIATOR ASS'Y	1	
4	26H-12462-00-00	. CAP, RADIATOR	1	
5	26H-12620-00-00	AIR SHROUD ASS'Y	1	
6	26H-12630-00-00	MOTOR ASSEMBLY	1	
7	26H-12611-00-00	FAN	1	
8	98501-05010-00	SCREW, PAN HEAD	3	
9	92901-05600-00	WASHER, PLATE	3	
10	95301-05600-00	NUT	1	
11	11H-12673-00-00	WASHER	1	
12	92990-05300-00	WASHER, INTERNAL TOOTH .	1	
13	90119-06044-00	BOLT, WITH WASHER	3	
14	90480-18276-00	GROMMET	2	
15	90387-07037-00	COLLAR	2	
16	90480-19283-00	GROMMET	2	
17	90387-06033-00	COLLAR	2	
18	97016-06020-00	BOLT	4	
19	92906-06100-00	WASHER, SPRING	4	




RADIATOR - HOSE

Ref. No.	Part Number	Description	Qty	Remarks
30	26H-12576-01-00	HOSE 1	1	
31	26H-12579-01-00	HOSE 4	1	
32	26H-12479-01-00	JOINT	1	
33	26H-12577-01-00	HOSE 2	1	
34	90467-23067-00	CLIP	4	
35	90460-38285-00	CLAMP, HOSE	2	
36	26H-1246A-02-00	COVER 1	1	
37	26H-11167-00-00	PIPE, BREATHER 2	2	
38	26H-1246E-02-00	COVER 2	1	
39	26H-11116-00-00	JOINT, BREATHER	1	
40	¢26-H1258-40-00	JOINT, HOSE 3	1	
41	26H-12428-00-00	GASKET, HOUSING COVER 2 .	1	
42	91311-06016-00	BOLT, SOCKET HEAD	4	
43	26H-12427-00-00	GASKET, HOUSING COVER 1 .	1	
44	90445-162A0-00	HOSE	1	
45	90467-14015-00	CLIP	2	
46	90413-12017-00	WAY 3	1	
47	90445-11637-00	HOSE	1	
48	90467-11102-00	CLIP		




OIL PUMP

Ref. No.	Part Number	Description	Qty	Remarks
1	26H-13300-01-00	OIL PUMP ASSEMBLY	1	
2	26H-13325-00-00	. GEAR, PUMP DRIVEN (28T) .	1	
3	99009-11400-00	. CIRCLIP	1	
4	99530-10014-00	PIN, DOWEL	2	
5	91316-06025-00	BOLT	3	
6	26H-13351-01-00	GEAR, PUMP IDLE 1 (16T)	1	
7	26H-13342-00-00	SHAFT, IDLE GEAR	1	
8	26H-13361-00-00	GEAR, PUMP IDLE 2 (15T)	1	
9	99009-12400-00	CIRCLIP	2	




OIL FILTER

Ref. No.	Part Number	Description	Qty	Remarks
1	26H-13447-01-00	COVER, oil element (26H-13447-00)	1	
2	1J7-13441-10-00	ELEMENT, OIL CLEANER	1	
3	93211-17317-00	O-RING	1	
4	90501-18433-00	SPRING, COMPRESSION	1	
5	90201-21608-00	WASHER, PLATE	1	
6	2H7-13340-00-00	BY-PASS VALVE ASSEMBLY .	1	
7	93210-16314-00	. O-RING	1	
8	26H-13417-01-00	COVER, STRAINER	1	
9	26H-Y1319-01-00	DELIVERY PIPE ASS"Y	1	
10	93210-13361-00	. O-RING	1	
11	93210-14637-00	O-RING	1	
12	93210-06667-00	O-RING	4	
13	26H-15365-00-00	GROMMET	2	
14	26H-15366-01-00	GROM		




OIL FILTER

Ref. No.	Part Number	Description	Qty	Remarks
28	90201-11723-00	WASHER, PLATE	2	
29	99510-08016-00	PIN, DOWEL	2	
30	26H-13171-00-00	PIPE, DELIVERY 2	1	
31	93210-06667-00	O-RING	2	
32	26H-13416-00-00	PIPE, OIL 1 (26H-13416-01-00) .	1	
33	26H-13476-00-00	GASKET	1	
34	90401-08093-00	BOLT, UNION	1	
35	90201-08087-00	WASHER, PLATE	2	
36	90465-08193-00	CLAMP	1	



AIR FILTER


Ref. No.	Part Number	Description	Qty	Remarks
1	26H-13586-00-00	JOINT, carburetor 1	2	
2	26H-13596-00-00	JOINT, carburetor 2	2	
3	16G-13569-00-00	PLUG, BLIND	3	
4	90467-10039-00	CLIP	3	
5	93210-45578-00	O-RING	4	
6	91316-06020-00	BOLT, SOCKET HEAD	6	
7	¢90-11006-05-60	BOLT, hexagon socket head ..	2	
8	1AE-13575-00-00	BAND	4	
9	90445-08674-00	HOSE	1	
10	90467-08021-00	CLIP	2	
11	41R-14489-00-00	NOZZLE	1	
12	90445-090A9-00	HOSE	1	
13	90467-08092-00	CLIP	2	
14	26H-13907-00-00	FUEL PUMP COMP	1	
15	90387-060A7-00	. COLLAR	2	
16	90480-12475-00	. GROMMET	2	




AIR FILTER

Ref. No.	Part Number	Description	Qty	Remarks
30	90460-58015-00	CLAMP, HOSE	4	

CARBURETOR




Ref. No.	Part Number	Description	Qty	Remarks
55	(26H-14139-00-00)	CLIP, PIPE	1	
56	98580-05014-00	. SCREW, PAN HEAD	1	
57	(31M-14139-00-00)	CLIP, PIPE	1	
58	41V-26313-00-00	. CABLE, throttle 3	1	
59	41V-2631J-00-00	. CABLE, throttle 4	1	




EXHAUST

Ref. No.	Part Number	Description	Qty	Remarks
1	26H-14611-01-00	PIPE, exhaust 1	1	
2	26H-14631-01-00	PIPE, exhaust 3	1	
3	26H-14621-02-00	PIPE, exhaust 2	1	
4	26H-14612-00-00	NUT, ring	1	
5	90101-06576-00	BOLT	1	
6	92995-06100-00	WASHER, SPRING	1	
7	26H-14641-02-00	PIPE, exhaust 4	1	
8	26H-14612-00-00	NUT, ring	1	
9	90101-06576-00	BOLT	1	
10	92995-06100-00	WASHER, SPRING	1	
11	90430-38054-00	GASKET	4	
12	90179-08599-00	NUT	8	
13	26H-14715-01-00	BAND, MUFFLER	2	
14	90110-06054-00	BOLT, HEXAGON SOCKET HEAD	2	
15	26H-14618-00-00	RING, stopper	2	
16	26H-14613-01-00	GASKET, exhaust pipe	2	
17	26H-14615-01-00	JOINT, exhaust 1	1	
18	26H-14624-01-00	COVER, exhaust	1	
19	90101-06576-00			




EXHAUST

Ref. No.	Part Number	Description	Qty	Remarks
29	97013-08025-00	BOLT	2	
30	97313-08020-00	BOLT, HEXAGON	1	
31	97013-08025-00	BOLT	1	
32	26H-14772-01-00	STAY, muffler 2	1	
33	95821-08020-00	BOLT, FLANGE (95801-08020) .	2	
34	95601-08200-00	NUT, U	2	
35	26H-14711-02-00	MUFFLER 1	1	
36	3JJ-14653-00-00	GASKET, EXHAUST 4	1	
37	26H-14797-00-00	BAND, silence 4	1	
38	92901-08600-00	WASHER	1	
39	97013-08025-00	BOLT	1	
40	26H-14721-02-00	MUFFLER 2	1	
41	3JJ-14653-00-00	GASKET, EXHAUST 4	1	
42	26H-14796-00-00	BAND, silencer 4	1	
43	92901-08600-00	WASHER	1	
44	97013-08025-00	BOLT	1	
45	90201-10742-00	WASHER, PLATE	2	
46	90105-10271-00	BOLT, WASHER BASED	2	




CRANKCASE

Ref. No.	Part Number	Description	Qty	Remarks
1	26H-15100-02-00	CRANKCASE ASSEMBLY (26H-15100-01-00)	1	
2	26H-15138-00-00	. NOZZLE 1	2	
3	4G0-15138-00-00	. NOZZLE 1	1	
4	99530-10014-00	. PIN, DOWEL	1	
5	2H7-15336-00-00	DAMPER, ENGINE MOUNT 3 ..	2	
6	26H-15317-00-00	SPACER, ENG MOUNT	1	
7	90116-10411-00	BOLT, STUD	8	
8	90116-10411-00	BOLT, STUD	8	
9	26H-15417-01-00	COVER, cap	4	
10	26H-15326-00-00	DAMPER, engine mount 2	4	
11	98780-06016-00	SCREW, FLAT HEAD (92603-06016)	4	
12	90338-11152-00	PLUG	4	
13	2H7-15336-00-00	DAMPER, ENGINE MOUNT 3 ..	2	
14	36Y-15326-00-00	DAMPER, ENGINE MOUNT 2 (2H7-15326-01-00)	2	
15	4H7-15189-00-00	PLUG	1	
16	93210-20573-00	O-RING	1	
17	95811-06045-00	BOLT, flange (95812		




CRANKCASE

Ref. No.	Part Number	Description	Qty	Remarks
28	90105-10248-00	BOLT, WASHER BASED	4	
29	90105-10249-00	BOLT, WASHER BASED	2	
30	90201-10131-00	WASHER, PLATE	6	
31	26H-15113-00-00	PLATE	1	
32	26H-15381-00-00	PLATE, BEARING COVER	2	
33	90149-08152-00	SCREW	4	
34	26H-15383-00-00	PLATE, BEARING COVER	1	
35	98701-06014-00	SCREW, FLAT HEAD	3	
36	90465-08233-00	CLAMP	1	
37	¢90-46508-26-30	CLAMP	1	
38	98580-06012-00	SCREW, PAN HEAD	1	
39	90201-061A5-00	WASHER, PLATE	1	
40	2H7-15361-00-00	GAUGE, LEVEL	1	
41	2H7-15363-00-00	PLUG, OIL	1	
42	93210-27778-00	O-RING	1	
43	95801-12016-00	BOLT, FLANGE	1	
44	90201-12790-00	WASHER, PLATE	1	
45				




CRANKCASE - COVER

Ref. No.	Part Number	Description	Qty	Remarks
1	26H-15411-00-00	COVER, crankcase 1	1	
2	3JP-15451-00-00	GASKET, CRANKCASE COVER 1	1	
3	99530-10014-00	PIN, DOWEL	2	
4	91311-06030-00	BOLT, SOCKET HEAD	11	
5	90465-06234-00	CLAMP	1	
6	90465-08220-00	CLAMP	1	
7	98580-06010-00	SCREW, PAN HEAD (92503-06010)	1	
8	90340-14068-00	PLUG, STRAIGHT SCREW	1	
9	93210-14369-00	O-RING	1	
10	26H-15427-01-00	COVER, cap 2	1	
11	11H-15447-00-00	EMBLEM	1	
12	93210-45150-00	O-RING	1	
13	98780-06016-00	SCREW, FLAT HEAD (92603-06016)	2	
14	26H-15455-01-00	GASKET 1	1	
15	3JP-15421-00-00	COVER, CRANKCASE 2 (26H-15421-04)	1	
16	26H-15428-00-00	COVER, chain case 2	1	
	26H-15449-00-00	RING, RUBBER	1	
17				




CRANKCASE - COVER

Ref. No.	Part Number	Description	Qty	Remarks
27	4H7-15486-00-00	GROMMET	1	
28	90209-06096-00	WASHER	1	
29	98580-06008-00	SCREW, PAN HEAD	1	
30	3JP-15462-00-00	GASKET, CRANKCASE COVER 3	1	
31	99530-10014-00	PIN, DOWEL	2	
32	91311-06025-00	BOLT, SOCKET HEAD	7	
33	91311-06035-00	BOLT, SOCKET HEAD	2	
34	59J-15113-00-00	PLATE	1	
35	59J-15191-00-00	PLATE	1	




GENERATOR

Ref. No.	Part Number	Description	Qty	Remarks
1	¢90-89130-01-50	STATOR ASSEMBLY (26H-81410-10-00)	1	
2	26H-81450-10-00	ROTOR ASSEMBLY	1	
3	26H-81670-10-00	PICK-UP ASSEMBLY	1	
4	98580-06045-00	SCREW, pan head (98503-06045-00)	3	
5	92995-06100-00	WASHER, SPRING	4	
6	98503-06014-00	SCREW, PAN HEAD (92502-06016)	4	
7	90201-06643-00	WASHER, PLATE	4	




SECONDARY SHEAVE

Ref. No.	Part Number	Description	Qty	Remarks
1	26H-81800-10-00	STARTING MOTOR ASS'Y . . .	1	
2	26H-81847-00-00	. O-RING	1	
3	371-81847-20-00	. O-RING	2	
4	22U-81826-00-00	. BOLT	2	
5	371-81811-20-00	. BRUSH 1	1	
6	371-81812-20-00	. BRUSH 2	1	
7	1J7-81840-60-00	. BRUSH HOLDER ASSEMBLY	1	
8	95811-06025-00	BOLT, FLANGE	1	
9	95811-06055-00	BOLT, FLANGE (95802-06055)	1	




STARTER CLUTCH

Ref. No.	Part Number	Description	Qty	Remarks
1	26H-15514-00-00	GEAR 2 (42T)	1	
2	26H-15515-00-00	GEAR 3 (13T)	1	
3	26H-15522-00-00	SHAFT 2	1	
4	26H-15512-00-00	GEAR, IDLER 1 (27T)	1	
5	26H-15521-00-00	SHAFT 1	1	
6	26H-15517-00-00	GEAR, IDLER 2 (76T)	1	
7	11H-15580-00-00	STARTER CLUTCH OUTER ASSEMBLY	1	
8	90501-04623-00	. SPRING, COMPRESSION	3	
9	341-15583-05-00	. CAP, STR CLUTCH SPR -CLUTCH SPRING	3	
10	93615-12088-00	. PIN, DOWEL	3	
11	91316-08014-00	BOLT	3	
12	90201-350F3-00	WASHER, PLATE	1	




CLUTCH

Ref. No.	Part Number	Description	Qty	Remarks
1	26H-16150-00-00	PRIMARY DRIVEN GEAR COMP.	1	
2	26H-16154-00-00	PLATE, THRUST 1	1	
3	26H-16371-00-00	BOSS, CLUTCH	1	
4	26H-16385-00-00	RING, CLUTCH BOSS	1	
5	26H-16384-00-00	PLATE, SEAT	1	
6	26H-16383-00-00	SPRING, CLUTCH BOSS	1	
7	26H-16321-00-00	PLATE, FRICTION	1	
8	26H-16324-00-00	PLATE, CLUTCH 1	1	
9	26H-16331-01-00	PLATE, FRICTION 2	1	
10	26H-16307-00-00	PLATE, FRICTION 3	6	
11	26H-16324-00-00	PLATE, CLUTCH 1	6	
12	26H-16351-00-00	PLATE, PRESSURE 1	1	
13	90501-24734-00	SPRING, COMPRESSION	6	
14	90159-06010-00	SCREW, WITH WASHER		




CLUTCH

Ref. No.	Part Number	Description	Qty	Remarks
29	26H-W0098-00-00	. PUSH LEVER SEAL KIT	1	
30	90110-06035-00	BOLT, HEXAGON SOCKET HEAD	2	




MIDDLE DRIVE GEAR

Ref. No.	Part Number	Description	Qty	Remarks
1	2WE-17524-00-00	HOLDER	1	
2	90501-75638-00	SPRING, COMPRESSION	1	
3	2WE-17527-00-00	CAM, DRIVEN	1	
4	26H-W1751-00-00	MIDDLE GEAR COMP.	1	
5	90201-252K4-00	WASHER, PLATE	1	
6	90209-21281-00	WASHER	2	
7	93306-20901-00	BEARING (B6209RSH2-C2) ...	1	
8	90179-44328-00	NUT	1	
9	4X7-17531-00-15	SHIM, PINION (0.15T)	1	UR
	4X7-17531-00-30	SHIM, PINION (0.30T)	1	UR
	4X7-17531-00-50	SHIM, PINION (0.50T)	1	UR
10	93332-00028-00	BEARING	1	
11	90201-25634-00	WASHER, PLATE	1	
12	2H7-17571-01-00	SPACER, EXPANSION	1	
13	93332-00024-00	BEARING	1	
14	26H-17556-00-00	YOKE, JOINT	1	




SHIFT CAM - FORK

Ref. No.	Part Number	Description	Qty	Remarks
1	26H-18540-00-00	SHIFT CAM ASSEMBLY	1	
2	93306-90602-00	. BEARING	1	
3	90560-30234-00	. SPACER	1	
4	93603-10049-00	. PIN, DOWEL	1	
5	26H-18141-01-00	. PLATE, STOPPER	1	
6	26H-18185-00-00	. SEGMENT	1	
7	93604-17198-00	. PIN, DOWEL	5	
8	26H-18561-01-00	. PLATE, SIDE 1	1	
9	90151-06013-00	. SCREW, COUNTERSUNK ...	1	
10	90501-06022-00	. SPRING, COMPRESSION	1	
11	278-18542-00-00	. POINT, NEUTRAL	1	
12	278-18566-00-00	. PLATE, SIDE 2	1	
13	98701-05016-00	. SCREW, FLAT HEAD	1	
14	93604-21197-00	. PIN, DOWEL	1	
15	26H-18511-01-00	FORK, SHIFT 1	1	




SHIFT SHAFT

Ref. No.	Part Number	Description	Qty	Remarks
30	26H-18150-00-00	SHIFT LEVER ASS'Y	1	
31	97011-06020-00	BOLT	1	



FRAME


Ref. No.	Part Number	Description	Qty	Remarks
28	26H-2117U-00-00	COVER 6	1	
29	26H-2117W-00-00	COVER 8	1	
30	26H-2117X-00-00	COVER 9	1	
31	26H-2117Y-00-00	COVER 0	1	
32	26H-2117F-00-00	COVER	1	
33	1NL-W2810-00-00	TOOL KIT	1	
34	4W5-W2171-00-00	WHEEL LOCK ASSEMBLY (4X7-W2171-00)	1	
35	2X4-2811A-01-00	GAUGE, AIR	1	



59J110-5210

FENDER

Ref. No.	Part Number	Description	Qty	Remarks
28	90464-16025-00	CLAMP	1	




59J110-5220

SIDE COVER


Ref. No.	Part Number	Description	Qty	Remarks
55	92906-05600-00	WASHER, PLATE	2	
56	41R-21741-00-00	COVER, side 4	1	
57	98506-05012-00	SCREW, PAN HEAD	2	
58	92906-05600-00	WASHER, PLATE	2	
59	26H-2134K-00-00	BRACKET, horn	1	
60	26H-2134L-00-00	BRACKET, horn 2	1	
61	97016-08016-00	BOLT	2	
62	92906-08100-00	WASHER, SPRING	2	
63	26H-2177M-00-00	DAMPER, locating 3	1	
64	26H-2177N-00-00	DAMPER, locating 4	1	

SWING ARM

Ref. No.	Part Number	Description	Qty	Remarks
28	90201-120E6-00	WASHER, PLATE	1	
29	90185-12119-00	NUT, SELF-LOCKING	1	
30	26H-2217M-00-00	ARM 1	1	
31	90381-18049-00	BUSH, SOLID	2	
32	90387-124H1-00	COLLAR	2	
33	26H-22129-00-00	COVER, thrust 2	4	
34	90109-10720-00	BOLT	2	
35	90201-102A2-00	WASHER, PLATE	2	
36	90185-10037-00	NUT, SELF-LOCKING	2	
37	90338-20113-00	PLUG	1	



26H-10-3231




1NL110-8280


LEVELING UNIT

Ref. No.	Part Number	Description	Qty	Remarks
29	(31M-22957-00-00)	BRACKET, HOSE	1	
30	93210-34504-00	O-RING	1	

FRONT FORK



Ref. No.	Part Number	Description	Qty	Remarks
82	26H-23188-00-00	O-RING	4	
83	3J2-23147-00-00	O-RING	4	
84	31M-2318E-00-00	CONNECTOR	1	
85	26H-23153-00-00	RING, snap	2	
86	26H-23163-00-00	GASKET	2	



41R110.4320

REAR WHEEL

Ref. No.	Part Number	Description	Qty	Remarks
28	92901-20600-00	WASHER, WAVE	1	

